

## **Some helpful hints in how to exchange the battery in your oval face YES watch.**

Before proceeding on any step in this process make sure to study watch and module with a magnifier to gain understanding of how it is put together. Work on a solid table. Do not use excessive force.

1. Unscrew the 4 screws holding back plate in place.
2. While holding module firmly inside of case unclasp the battery bracket. Use a pointed tool to release clasp. Do not try to take module out of case. Remove CR2025 battery carefully, while still holding module firmly in case.
3. Reinsert a fresh CR2025 into battery slot and lock it in place by snapping the battery holding bracket into place.
4. Make sure O-ring is properly seated on back plate, position correctly, it is directional and then screw the 4 screws back onto watchcase. A couple of drops of fine oil smeared on the O-ring first and screws is not a bad idea. Once all 4 screws are in tighten them all firmly
5. Push all 4 buttons to test watch functionality. Watch will flash a display, sound the alarm and turn on the back light for 3 seconds.
6. If alarm does not sound unscrew back plate again and make sure alarm spring reaches alarm plate. Pull the spring gently outwards to extend it's reach.
7. Then set location and time.

If you have any questions contact me at 858 729 0703 or [bj@yeswatch.com](mailto:bj@yeswatch.com)

Thank you.  
Bjorn.